
ACCESSORIES



UNIVERSAL MAGNETIC BASE



- · Guaranteed firm and solid fixation of all 5 joints by tightening just one knob.
- · Multi nimble joint for instant fixation in any position. indicator not included.
- · Fixs dovetail and 3/8 " or 8mm stem indicators. Extra large reach - 10 - 1/2"
- · Unique design for longest life.
- · Also Available without magnetic base, M8×1.25 or threaded adaption.

POWER: 70KGS BASE: 64×53×49mm

CO-AX INDICATOR

MTI - CTR - IND.

- A unique approach to quick, accurate centering in boring and milling set-ups.
- Operates at any angle from HORIZONTAL to VERTI-CAL without any change, and from INTERNAL to EXTERNAL diameter by simply changing the feeler.
- Indicator dial remains stationary while the machine spindle rotates, leaving the operator with both hands free to accurately X-Y position the machine table, while conveniently observing the indicator.
- By using the CO-AX Indicator with the machine spindle running, exact operating conditions are simulated for the centering function since the influence of power transmission, lubricant flow, spindle bearing characteristics and torque are integrated into the indicator reading.
- No walking around the machine necessary No mirrors required No contortions Exact chuck-ing not necessary.





FISSOFLEX FLEXIBLE MAGNETIC BASE





LARGE FISSOFLEX - ARM ONLY Arm - 3300

- Multi nimble joint for instant fixation in any position
- Guaranteed firm and solid fixation of all 5 joints by tightening just one knob
- Large reach 280mm
- Unique design for longest life
- Fits dovetail and stem indicators





- Reach 200mm
- Fits Dovetail and 8mm stems

